



| ITEM NO. | PART NUMBER | DESCRIPTION | QTY. |
|----------|-------------|---------------------------------|------|
| 1 | 23-1141 | O-Ring | 1 |
| 2 | 23-1325 | O-Ring | 1 |
| 3 | 23-1331 | Backup Ring | 2 |
| 4 | 23-1332 | O-Ring | 1 |
| 5 | 23-1335 | O-Ring | 6 |
| 6 | 23-1343 | O-Ring | 2 |
| 7 | 23-1344 | O-Ring | 4 |
| 8 | 23-1345 | Backup Ring | 2 |
| 9 | 23-1400 | O-Ring | 2 |
| 10 | 23-1433 | Backup Ring | 1 |
| 11 | 40-0134 | Spring Plate | 1 |
| 12 | 40-0135 | Lock Handle | 1 |
| 13 | 40-0136 | Adjusting Screw & Handle | 1 |
| 14 | 40-0140 | Plug, Adjustment Head | 1 |
| 15 | 40-0143 | Spring, Outer | 1 |
| 16 | 40-0144 | Spring, Inner | 1 |
| 17 | 40-0330 | Piston Guide | 1 |
| 18 | 40-0331 | Seal Container | 1 |
| 19 | 40-0332 | Spring, Supply | 1 |
| 20 | 40-0333 | Seal Cage, Vent | 1 |
| 21 | 40-0334 | Seal Ring, Vent | 2 |
| 22 | 40-0335 | Seal Cage, Inlet | 1 |
| 23 | 40-0336 | Seal Ring, Supply | 2 |
| 24 | 40-0337 | Flange | 2 |
| 25 | 40-0339 | Flange, Lower | 1 |
| 26 | 40-0340 | Flow Plate, Supply & Vent KR-12 | 2 |
| 27 | 40-0341 | Body | 1 |
| 28 | 40-0345 | Adapter | 1 |
| 29 | 40-0388 | Adjustment Head | 1 |
| 30 | 40-0863 | Spring, Vent | 1 |
| 31 | 40-1161 | Upper Bearing Body | 1 |
| 32 | 40-1163 | Lower Bearing Body | 1 |
| 33 | 50-0069 | Bolt, SHCS | 22 |
| 34 | 50-0084 | Bolt, SHCS | 4 |
| 35 | 50-0157B | Bearing, NTA-1220 | 1 |
| 36 | 50-0157T | Thrust Washer, TRB-1220 | 2 |
| 37 | 50-0239 | Grip, Handle | 3 |

PacSeal Hydraulics Inc.

VALVES, ACCUMULATORS, CONTROLS

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF PacSeal Hydraulics. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF PacSeal Hydraulics IS PROHIBITED.

| | | | |
|-------------------|------------|--------------|-----|
| TITLE | SIZE | DWG. NO. | REV |
| Regulator, KR-12M | A | 40-1663 | 5 |
| SCALE: 1:3 | WEIGHT: 31 | SHEET 2 OF 2 | |