



Conversion Procedure:

1. Loosen #21 (Locking Handle, 40-0135)
2. Remove #22 (Adjusting Screw, 40-0136) to relieve compression on spring
3. Remove #23 (Plug, Adjustment Head 40-0140)
4. Install #4, #3 & #2
5. Adjust Outlet pressure as desired. Lock down Adjustment Screw #2 by tightening Jam Nut #3
6. Install #1 and #5

PACSEAL HYDRAULICS INC.

VALVES, ACCUMULATORS, CONTROLS

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF PacSeal Hydraulics. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF PacSeal Hydraulics IS PROHIBITED.

TITLE: Kit, KR-Tamper Proof Conversion

SIZE A	DWG. NO. 40-3175	REV 1
SCALE: 1:3		SHEET 1 OF 1

40-3175